





Physical Media

CS 438: Spring 2014

Instructor: Matthew Caesar

<http://www.cs.illinois.edu/~caesar/cs438>



Today: Physical Media

- Networks are made up of devices and communication links
- Devices and links can be physically threatened
 - Vandalism, lightning, fire, excessive pull force, corrosion, wildlife, wear and tear
 - Wiretapping, crosstalk, jamming
- We need to make networks mechanically resilient and trustworthy

AT&T Cables Vandalized, \$250,000 Reward Offered for Information

Two of the company's main fiber optic lines were cut in Del Mar Thursday morning, leading to a widespread communications outage

By Tony Shin and Monica Garske | Friday, Jun 15, 2012 | Updated 7:00 AM PST

North County experienced a widespread communications outage Thursday after an unknown person or vandals deliberately cut two main fiber optic lines belonging to AT&T.

Cable theft costs Telkom R863m

03 MAR 2008 12:11 - STAFF REPORTER

Recommend < 0 Tweet < 0

Copper cable theft between April last year and the end of January has cost Telkom R863-million, the telecommunications provider said on Monday. In a statement, Telkom said the "alarming surge" in copper cable theft is the biggest inhibitor in its capability to improve services.

Copper cable theft between April last year and the end of January has cost Telkom R863-million, the telecommunications provider said on Monday.

In a statement, Telkom said the "alarming surge" in copper cable theft is the biggest inhibitor in its capability to improve services.

SFGate

Fiber Optic Cable System Vandalism A National Security Problem

On April 9th a criminal incident impacting nearly a million people in three counties of California was largely unnoticed by the media, both nationally and locally. The implications far beyond the scale and scope of the incident affecting millions of Americans. What was it all about?

Someone or a group of people cut a fiber-optic cable system in San Jose, California. No one knows who did it, but the implications are dire. Homes, banks, and supermarkets. No one could get information from the Internet. The fact is, it is not known, but imagine not being able to do so for any reason especially if they need your service, because access to the Internet is a

Someone or a group of people cut a fiber-optic cable system in San Jose, California. No one knows who did it, but the implications are dire. Homes, banks, and supermarkets. No one could get information from the Internet. The fact is, it is not known, but imagine not being able to do so for any reason especially if they need your service, because access to the Internet is a



THE WALL STREET JOURNAL

A Look inside Verizon's Flooded Communications Hub

Eleven years after the 9/11 terrorist attacks, Verizon Communications Inc. is once again scrambling to repair severe damage to a key switching facility inside its historic headquarters building in lower Manhattan.



The massive facility for interconnecting key communications lines sustained heavy damage after planes struck the

\$50,000 REWARD

Verizon takes great pride in the reliability of its service and quickly makes necessary repairs. Federal and State laws carry stiff penalties (imprisonment and fines) for the intentional destruction of telecommunications facilities or assaults against Verizon workers.


Verizon is offering a reward of up to \$50,000 to the first person who provides information leading to the arrest and prosecution of any person who intentionally:

- Damages Verizon cables or facilities
- Causes or attempts to cause physical injury to any individual(s), especially targeted

This lecture

- Keeping physical communication secure
- Overview of copper, optical, and wireless communication technologies
- Wire mechanics, attacks, and countermeasures

How can two computers communicate?




- Encode information into physical “signals”
- Transmit those signals over a transmission medium

Types of Media

- Metal (e.g., copper)
- Light (e.g., optical fiber)
- EM/RF (e.g., wireless 802.11)

Security of Copper-based Networks








Making physical connections secure: Key Metrics

- Mechanical strength
 - Flex life, turn radius, breaking strength, torsional and compression strength, flammability, specific gravity, ease of deployment (stripping/termination), corrosion resistance, temperature requirements
- Noise/RF interference protection
- Cost


Background: Atoms

- Made up of positively-charged **protons**, negatively-charged **electrons** and Neutrons
- Electrons contained in **orbits**
- Highest orbit is called the **valence shell**
- Valence electrons can break off, forming **free electrons**




Background: Electrical Current

- Usually free electrons hop around randomly
- However, outside forces can encourage them to flow in a particular direction
 - Magnetic field, charge differential
 - This is called **current**
 - We can vary properties of current to transmit information (via waves, like dominos, as electron **drift velocities** are very slow)




No charge differential



Charge differential

Conductors vs. Insulators

- **Conductor:** valence electrons wander around easily
 - Copper, Aluminum
 - Used to carry signal in cables
- **Insulator:** valence electrons tightly bound to nucleus
 - Glass, plastic, rubber
 - Separates conductors physically and electrically
- **Semiconductor:** conductivity between insulator and conductor
 - Can be easily made more conductive by adding impurities



Material	Resistivity (ohm m)
Glass	10^{12}
Mica	$9 \cdot 10^{13}$
Quartz	$5 \cdot 10^{16}$
Copper	$5 \cdot 10^{-8}$

Common Conductors


- **Copper**: cheap, lower operating temperature, lower strength
- **Aluminum**: lightweight and cheap, but less conductive than copper
- **Silver**: most conductive material, but very high price
- **Nickel**: improved strength, higher resistance
- **Tin**: improved durability and strength, but higher resistance

Coating Copper to Improve Resilience

- Coating copper can provide additional properties
 - Done by “hot dipping” or electroplating
- **Tinned copper**: corrosion protection, easier to solder
 - Industrial ethernet deployments, environments exposed to water such as ships
- **Silver/gold plated copper**: better conduction, operation over wider temperature range (-65°C to 200°C). Commonly used in aerospace applications
- **Nickel-plated copper**: corrosion protection, operation over wider temperature range (thick plating can withstand 750 deg C), reduced high-frequency loss




Reducing Resistance from the Skin Effect

- Alternating electric current flows mainly at the “skin” of the conductor
 - Due to “turbulent” eddy currents caused by changing magnetic field
- Stranding helps, but not as much as you might think
 - Touching surface area acts like single conductor
 - Individually-insulating strands (Litz wire) helps
- Coating with low-resistance material can leverage this property
 - E.g., silver-tinned copper





Improving Strength with Stranding

- **Solid** vs **Stranded** conductors
 - Solid: Inexpensive and tough, solid seating into jacks and insulation
 - Stranded: Increased flexibility and flex-fatigue life, increased conductivity
- Stranding type affects wire properties
 - **Bunched**: Inexpensive and simple to build, can be bulkier (circle packing problem)
 - **Concentric**:
 - Unilay: lighter weight and smaller diameter; greater torsional flex
 - Contra-helical: Greater mechanical strength and crush resistance; greater continuous flex
 - More twists → improve strength
- Ethernet comes in both solid (plenum) and stranded (standard)





Noise, Jamming, and Information Leakage


- When you move a conductor through a magnetic field, electric current is induced (**electromagnetic induction**)
 - EMI is produced from other wires, devices
 - Induces current fluctuations in conductor
 - Problem: **crosstalk**, conducting noise to equipment, etc





Shielding Noise



- Enclose insulated conductor with an additional conductive layer (shield)
 - Reflect, absorb (Faraday cage), or conduct EMF to ground
- Types of shielding
 - Metallic foil vs. Braid shield
 - Foil is cheaper but poorer flex lifetime
 - Braid for low freq and EMI, Foil for high freq and RFI
 - Foil widely used in commodity Ethernet
 - Combining foil+braid gives best shielding





Reducing noise with Twisted Pairing



- Differential signaling: transmit complementary signals on two different wires
 - Noise tends to affect both wires together, doesn't change relative difference between signals
 - Receiver reads information as difference between wires
 - Part of Ethernet standard, Telegraph wires were first twisted pair

Reducing noise with Twisted Pairing



- Disadvantages:

- EMI protection depends on pair twisting staying intact → stringent requirements for maximum pulling tension and minimum bend radius (**bonded TP** can help)
- Twisted pairs in cable often have different # of twists per meter → color defects and ghosting on video (CCTV)

Insulators

- Insulators separate conductors, electrically and physically
- Avoid air gaps: ionization of air can degrade cable quality
- ...





Cable Ratings



- **Plenum rated** (toughest rating)
 - National Fire Protection Standard (NFPA) 90A
 - Jacketed with fire-retardant plastic (either low-smoke PVC or FEP)
 - Cables include rope or polymer filament with high tensile strength, helping to support weight of dangling cables
 - Solid cable instead of stranded
 - Restrictions on chemicals for manufacture of sheath → reduced flexibility, higher bend radius, and higher cost
- **Riser cable**: cable that rises between floors in non-plenum areas
- **Low smoke zero halogen**: eliminates toxic gases when burning, for enclosed areas with poor ventilation or around sensitive equipment



Submarine Cables





Physical Tapping

- Conductive Taps
 - Form conductive connection with cable
- Inductive Taps
 - Passively read signal from EM induction
 - No need for any direct physical connection
 - Harder to detect
 - Harder to do with non-electric conductors (eg fiber optics)




Tapping Cable: Countermeasures

- Physical inspection
- Physical protection
 - E.g., encase cable in pressurized gas
- Use faster bitrate
- Monitor electrical properties of cable
 - TDR: sort of like a hard-wired radar
 - Power monitoring, spectrum analysis
 - More on this later in this lecture


Case Study: Submarine Cable (Ivy Bells)

- 1970: US learned of USSR undersea cable
 - Connected Soviet naval base to fleet headquarters
- Joint US Navy, NSA, CIA operation to tap cable in 1971
- Saturation divers installed a 3-foot long tapping device
 - Coil-based design, wrapped around cable to register signals by induction
 - Signals recorded on tapes that were collected at regular intervals
 - Communication on cable was unencrypted
 - Recording tapes collected by divers monthly



Case Study: Submarine Cable (Ivy Bells)

- 1972: Bell Labs develops next-gen tapping device
 - 20 feet long, 6 tons, nuclear power source
 - Enabled
- No detection for over a decade
 - Compromise to Soviets by Robert Pelton, former employee of NSA
- Cable-tapping operations continue
 - Tapping expanded into Pacific ocean (1980) and Mediterranean (1985)
 - USS Parche refitted to accommodate tapping equipment, presidential commendations every year from 1994-97
 - Continues in operation to today, but targets since 1990 remain classified




A Challenge for You...

- You're operating a long network cable
 - Rail-based fiber optic, transatlantic cable...
- It stops working
- What do you do?


Locating Anomalies with Time-Domain Reflectometry (TDR)

- A tool that can detect and localize variations in a cable
 - Deformations, cuts, splice taps, crushed cable, termination points, sloppy installations, etc.
 - Anything that changes impedance
- Main idea: send pulse down wire and measure reflections
 - Delay of reflection localizes location of anomaly
 - Structure of reflection gives information about type of anomaly

Motivation: Wave Pulse on a String




Motivation: Wave Pulse on a String



TDR Examples




Melted cable (electrical short)



TDR: Inverted reflection



Cut cable (electrical open)



TDR: Reflection ³⁶

TDR Example: Cable Moisture



Water-soaked/flooded cable

TECHNOLOGY | Updated November 1, 2012, 11:01 a.m. ET

A Look inside Verizon's Flooded Communications Hub




Kevin Hagen for the Wall Street Journal


Several floors of Verizon's headquarters are flooded at 140 West St. in Manhattan.

Eleven years after the 9/11 terrorist attacks, [Verizon Communications Inc.](#)

[VZ-0.23%](#) is once again scrambling to repair severe damage to a key switching facility inside its historic headquarters building in lower Manhattan.




TDR Examples



Faulty Amplifier



Wire Tap



Against wildlife



Rodents



Moths



Cicadas





Ants



Crows


Protection against wildlife



- Rodents (squirrels, rats, mice, gophers)
 - Chew on cables to grind foreteeth to maintain proper length
- Insects (cicadas, ants, roaches, moths)
 - Mistake cable for plants, burrow into it for egg laying/larvae
 - Ants invade closures and chew cable and fiber
- Birds (crows, woodpeckers)
 - Mistake cable for twigs, used to build nests
- Underground cables affected mainly by rats/termites, aerial cables by rodents/moths, drop cables by crows, closures by ants

Countermeasures against wildlife

- Use High Strength Sheath cable
 - PVC wrapping stainless steel sheath
 - Performance studies on cable (gnathodynamometer)
- Cable wrap
 - Squirrel-proof covers: stainless steel mesh surrounded by PVC sheet
- Fill in gaps and holes
 - Silicone adhesive
- Use bad-tasting cord
 - PVC infused with irritants
 - Capsaicin: ingredient in pepper spray, irritant
 - Denatonium benzoate: most known bitter compound



Physical layer: Optical Networks

Why optical networks?

- Today's long-haul networks are based on optical fiber
 - >50% of Internet traffic goes over fiber optics, and increasing
 - Optical is the best choice for high datarate, long-distance
- Benefits of optical:

Optical fiber vs. copper: the choice is clear		
	Optical Fiber	Copper
Capex Cost (2,000-user optical LAN)	< \$300,000	>\$1,000,000
Lifecycle	30-50 years	5 years
Distance	12 miles	300 feet
Weight (per 1,000 ft.)	4 lbs.	39 lbs.
Energy Consumed	2 watts per user	more than 10 watts per user
Maximum Bandwidth	69 Tbps	10 Gbps
Security	Hard to tap, easy to alarm	Emits EMI

**

**

** (Note these are amortized numbers -- amortized cost and energy use can be much higher in smaller, local LANs)

Why is fiber better?

- Attenuation per unit length
 - Reasons for energy loss
 - copper: resistance, skin effect, radiation, coupling
 - fiber: internal scattering, imperfect total internal reflection
 - So fiber beats coax by about 2 orders of magnitude
 - e.g. 10 dB/km for thin coax at 50MHz, 0.15 dB/km $\lambda = 1550\text{nm}$ fiber
- Noise ingress and cross-talk
 - Copper couples to all nearby conductors
 - No similar ingress mechanism for fiber
- Ground-potential, galvanic isolation, lightning protection
 - Copper can be hard to handle and dangerous
 - No concerns for fiber

Why not fiber?

- Fiber beats all other technologies for speed and reach
- But fiber has its own problems
 - Harder to splice, repair, and need to handle carefully
- Regenerators and even amplifiers are problematic
 - More expensive to deploy than for copper
- Digital processing requires electronics
 - So need to convert back to electronics
 - Conversion is done with an **optical transceiver**
 - Optical transceivers are expensive
- Switching easier with electronics (but possible with photonics)
 - So pure fiber networks are topologically limited:
 - point-to-point
 - rings



copper  fiber

Main components of a fiber-optic network



- Fiber
- Light sources and receivers
- Amplifiers
- Couplers
- Modulator
- Multiplexor
- Switch

Optical Fibers

- Very pure and transparent silica glass
 - **Jacket/buffer** protects the rest of the fiber
- **Core** transmits light
 - Some fibers also use cladding to transmit light
- **Cladding** and **core** transmit light
 - Cladding has lower **refractive index** than core
 - Cladding causes light to be confined to the core of the fiber due to **total internal reflection** at the boundary between the two
 - Beyond **critical angle**, all light is reflected
 - Some fibers support cladding modes where light propagates in the cladding as well
 - Most fibers coat cladding with polymer with slightly higher refractive index, to rapidly attenuate light propagating in cladding
 - Exception: double-clad fiber, which supports a mode in both its cladding and its core




Inside an optical fiber




- **Refractive index** of core (n_1) is bigger than that of the cladding (n_2)
 - Done by doping core with impurity (eg Germanium Oxide)
 - Goal: cause light to be confined to the core due to **total internal reflection**

Keeping the light in the core with Total Internal Reflection




- Case 1: angle of incidence is **less** than the critical angle
 - $\theta_i < \theta_c$ $\theta_c = \sin^{-1}(n_2/n_1) \rightarrow$ All light is reflected
 - This really is 100% reflection – wouldn't have such low-loss fibers otherwise



- Case 2: angle of incidence is **greater** than the critical angle
 - $\theta_i > \theta_c \rightarrow$ Some light is reflected, but some is also refracted




Acceptance angle



- Critical angle determines acceptance angle of light going in
 - Light received at too much of an angle will have high attenuation
 - **Numerical aperture (NA)**: size of cone of light input that will be totally internally reflected
 - $NA = n_0 \sin(\theta_0)$


Multiplexing Techniques

- Wavelength Division Multiplexing (WDM)
 - Different sources = different colors
- Optical Time Division Multiplexing (OTDM)
 - Different sources = different time slots
- Optical Code Division Multiplexing (OCDM)
 - Derive a set of orthogonal “codes”
 - Different sources = different codes




Single- vs. Multi-mode optical fiber

- Single-mode fiber is designed to carry a single “ray” (mode) of light
- Multi-mode fiber carries multiple rays/modes
 - Larger core than single mode
 - Higher loss, hence used over shorter distances (within a building or on a campus)
 - Typical rates of 10Mbit/s to 10Gbit/s of lengths up to 600 meters



Multi-mode



Single-mode

Signal attenuation in optical fibers

- Fibers are much more efficient transmitters than copper wires
- Certain wavelengths have especially low loss
 - 1300 and 1500 μm \rightarrow 0.1 dB/km (\sim 2% per km loss) \rightarrow very efficient
 - Very efficient due to total internal reflection
- Why is there any loss at all?
 - Why are certain wavelengths more affected by loss?



Why is there loss in optical fibers?

- Rayleigh scattering
- Material absorption
- Micro- and Macrobending
- Chromatic dispersion

Why is there loss in optical fibers?


- **Rayleigh scattering**

- Light hits and bounces off particles (individual atoms or molecules)
- Blue is scattered more than other colors, as it travels in smaller, shorter waves
- Same reason sky is blue during day and red at night
- Bigger effect at smaller wavelengths



Why is there loss in optical fibers?


- **Material absorption**
 - Intrinsic absorption in infrared and ultraviolet bands
 - Impurities in optical fibers
 - Most important one: water in the form of hydroxyl ions, causing losses at 950, 1250, and 1380 nm




Why is there loss in optical fibers?

- **Mechanical issues**

- **Microbending:** Local distortions of fiber geometry/refractive index



- **Macrobending:** excessive fiber curvature
 - Occurs when installing fiber





Macrobending example

- <http://www.youtube.com/watch?v=1ex7uTQf4bQ>

Chromatic dispersion

- Velocity of light is 3×10^8 m/s in vacuum
 - But in a transparent medium, phase velocity of light wave depends on its frequency
 - Red, which has longer wavelength than blue, will travel faster
 - In glass, red travels at 66.2% of c , blue travels at 65.4% of c
 - This is what causes rainbows



Fiber Type	Wavelength	Fiber attenuation / km *	Fiber attenuation / km #	Connector Loss	Splice Loss
Multimode 50/125µm	850nm	3.5 dB	2.5 dB	0.75 dB	0.1 dB
	1300nm	1.5 dB	0.8 dB	0.75 dB	0.1 dB
Multimode 62.5/125µm	850nm	3.5 dB	3.0 dB	0.75 dB	0.1 dB
	1300nm	1.5 dB	0.7 dB	0.75 dB	0.1 dB
Single Mode 9µm	1310nm	0.4 dB	0.35 dB	0.75 dB	0.1 dB
Single Mode 9µm	1550nm	0.3 dB	0.22 dB	0.75 dB	0.1 dB

**These values are per TIA/EIA and other industry specifications and are the values used by Transition Networks in all link loss calculations.*

#These values are one example of the performance that can be obtained with a new fiber installation.

Laying Fiber



- How to lay cable over long distances?
 - Rail lines sell **easements** to permit laying of cable along rail line right-of-ways
 - Digging up and laying is the expensive part
 - So, lay extra fiber and leave it dark (“dark fiber”)
 - Light it up when more capacity needed

Optical components



- Transmitter/receiver
- Optical amplifier
- Optical coupler/splitter
- Optical delay units (packet buffering)

Optical transmitters/receivers

- Transmitting light with **lasers**
 - Laser diodes: created by doping thin layer on crystal wafer to create a p-n junction
 - **Fiber Laser: Gain medium** (doped optical fiber) amplifies beam through **spontaneous emission**
- Receiving light with **photodetectors**
 - Inverted diode: apply reverse voltage across p-n junction, light excites current



Optical Amplifiers



- Amplifies optical signal without converting it to electricity
- Doped Fiber Amplifier: signal is amplified through interaction with doping ions
- Used to correct attenuation
 - Placed every 100km on long-haul links

Optical Coupler/Splitter

- **Splitter**: The optical version of a copying machine
 - Divides one incoming signal into multiple signals
 - Made from half-silvered mirror, or two joined prisms
 - Adjusted so that half of light is reflected and other half is refracted
 - **Coupler**: joins two signals
- Uses:
 - Getting two copies of a signal (wiretapping)






FIGURE 12.3 Directional coupler consisting of two fibers whose cores are brought close to each other. Due to interaction between the fibers, there is a periodic exchange of power between the two fibers, as shown in the lower part of the figure.



Optical Networks: Vulnerabilities and Countermeasures

Service Disruption Attacks



- Goal: cause delay, service denial, QoS degradation, spoofing
- Can easily cut/disrupt optical fiber
- Can bend fiber to radiate light in/out of fiber
- In-band Jamming
 - Attacker injects signal to confound receiver
 - Signals flow through nodes without electrical regeneration → attack can easily spread through network

Service Disruption Attacks

- Out-of-band jamming: attacker jams signal by exploiting leaky components
 - Exploits crosstalk in various components
- Examples
 - Attacker can hop wavelengths by sending very strong signal
 - WSSs can have crosstalk levels of -20dB to -30dB
 - Inject signal on different wavelength but within amplifier passband
 - Gain for comm signal is robbed by the attack signal
 - Electromagnetic Pulses (EMP) could cause both in-band and out-of-band jamming

Tapping Attacks

- Contemporary demultiplexers exhibit crosstalk levels of 0.03% to 1%
 - Leak a little bit of the signal on the wrong path, attacker can listen in
- Fibers can leak across wavelengths due to chromatic dispersion
- Optical amplifiers can leak due to gain competition
 - Attacker can co-propagate a signal on a fiber and observing cross-modulation effects
- Tapping can be combined with jamming
 - Tap, and inject a correlated signal downstream of the tap point
 - Very harmful to users with low SNR

Mitigating Attacks on Optical Networks

- Optical Limiting Amplifier: limits output power to specified maximum
 - Limiting light power limits crosstalk and service disruption attacks
- Band-Limiting Filters: discard signals outside a certain bandwidth
 - Can prevent gain competition in optical amplifiers

Mitigating Attacks on Optical Networks

- Physically strengthen or armor the cladding
 - Bury cable in concrete, enclose cable in pressurized pipe
 - Usually very expensive
- Choose devices with lower crosstalk
- Choose more robust transmission schemes
 - Coding to protect against jamming
 - Intelligent limiting of signals to certain bandwidths/power constraints
- Architectural techniques
 - Avoid easily-compromised links for sensitive communications
 - Judicious wavelength assignment to separate trusted from non-trusted users

Detecting Attacks

- Power detection: compare received optical power to expected optical power
 - Too much: jamming attack?
 - Too little: tapping?
 - Challenges: slight changes are difficult to detect; small but detectable changes result from component aging and fiber repairs. Tuning problem.
 - Sporadic jamming might harm BER but might not change power levels enough to show up

Detecting Attacks

- Optical spectrum analysis: measure spectrum of optical signal
 - Can help localize gain competition attacks
 - Require additional processing time and hence can slow detection time
- Pilot tone: known signal, different carrier frequency, but traveling on same path as data
 - Used to detect transmission disruption

Detecting Attacks

- Optical TDR: like pilot tones, but analyze echo
 - Used to detect attacks involving fiber tampering, e.g. in-line eavesdropping
 - Challenge: EDFAs are sometimes unidirectional, not reflecting the echo
 - May require bi-directional amplification

Where to go from here?

- CS 425: Distributed Systems
- CS 423: Operating Systems
- CS 461-463: Computer and Network Security
- Also graduate versions of the above

- CS 538: Advanced Computer Networks
- Industry internships
- Research projects (397, 497, etc)